

**Push Button Bleed Valve Upgrade 08B3-BL01 1/8" BSP  
Suits standard MDE Charging Heads & similar units.**

**FITTINGS INSTRUCTIONS**



1. First remove the existing bleed screw from the bottom of the unit.
2. Ensure the bleed screw port is clean and free from any debris.
3. Insert the supplied plastic seal into the bleed screw port.
4. Screw in the new bleed valve until finger tight against the seal, and then rotate clockwise with a spanner to orient to the desired position.



5. The unit is now ready for use.

web: [www.best-fittings.co.uk](http://www.best-fittings.co.uk) email: [technical@best-fittings.co.uk](mailto:technical@best-fittings.co.uk)

Tel: (UK) 0845 456 1185 Intl: 0044 1747 312672