

Push Button Bleed Valve Upgrade 08B3-BL02 M10 x 1
Suits standard MDE Jubilee Valves & similar units.

FITTINGS INSTRUCTIONS



1. First remove the existing bleed screw from the side of the valve. You may need to remove a small screw from the top or bottom of the valve in order to remove the bleed screw.
2. Ensure the bleed screw port is clean and free from debris.
3. Insert the supplied plastic seal into the bleed screw port.
4. Screw in the new bleed valve until finger tight against the seal, and then rotate clockwise with a spanner to orient in the desired position.



5. The unit is now ready for use. The small screw does not need to be re-installed.